



Laser Technology, Inc.

MapStar® TruAngle®

User's Manual



© LTI 2014 MapStar TruAngle 0144849

 LASER[®]
TECHNOLOGY
Measurably Superior[®]

Copyright Notice:

Information in this document is subject to change without notice and does not represent a commitment on the part of Laser Technology, Inc. No part of this manual may be reproduced in any form or by any means, electronic or mechanical, including photocopying, recording, or information storage and retrieval systems, for any purpose other than the purchaser's personal use, without the express written consent of Laser Technology, Inc.

Copyright (c)[2010-2014] Laser Technology, Inc. All Rights Reserved.
Unauthorized duplication, in whole or in part, is strictly prohibited.

First Edition: December 2010
Second Edition: January 2012
Third Edition: November 2014

Trademarks:

MapStar, TruAngle, TruPulse, TruSpeed, Impulse, UltraLyte and Criterion are registered trademarks of Laser Technology, Inc. All other trademarks are the property of their respective owner.

Patents:

This product is covered by pending patent applications and the following issued patent: 5,859,693

How to Contact LTI:	Street Address:	6912 S. Quentin Street Centennial, CO 80112 USA
	Phone:	1-303-649-1000
		1-800-790-7364 (USA and Canada)
	Fax:	1-649-9710
	Web Site:	www.lasertech.com
	Email:	service@lasertech.com

Table of Contents

Precautions	2
Section #1 - Introducing the MapStar TruAngle	2
Basic Package	3
Accessories	3
Section #2 - Quick Start	3
Section #3 - Using the TruAngle	4
Loading the Batteries	4
Battery Indicator	4
Attaching the Side Brackets and the Laser	5
Connecting the Cables	6
Cable Crimp	6
Leveling the TruAngle	6
Fine Adjust and Friction Lock	7
Button Names and Functions	7
Power ON the TruAngle	7
Extend the Display Segment Test	8
Power OFF the TruAngle	8
Display the Firmware Version Number	8
Turn the LCD Backlight On or Off	8
Indexing the Encoder	9
Zeroing the Unit	9
Entering A Non-Zero Backsight	9
Removing the Non-Zero Backsight Value	10
Taking a Measurement	10
Error Codes	10
Section #4 - Managing Serial Data	11
NMEA Compliance	11
Laser Settings	11
Remote Triggering	11
Format Parameters	12
Serial Ports Pin-out Assignments	12
Serial Commands	12
Serial Requests	12
Serial Commands	13
TruPulse Series and TruSpeed Sx Only	14
Error Messages	15
Section #5 - Caring for the TruAngle	16
Section #6 - Troubleshooting & Tips	17
Section #7 - Specifications	18
Section #8 - LTI Limited Warranty	19
Index	20

Precautions

Do not expose to extreme temperatures.

TruAngle components are rated for a operating temperature range of -22° to 122° F (-30° to 50° C).
Storage temperature range: -40° to 176° F (-40° to 80° C).

Do not expose to severe mechanical shock.

To do so may damage the TruAngle's encoder or associated electronics.
See the required procedure for indexing the encoder ([Page 9](#)).

Do not expose to excessive moisture or dust.

The TruAngle is rated IP54 - water & dust resistant. See [Page 16](#) for information about the care and maintenance of the TruAngle.

Section #1 - Introducing the MapStar TruAngle

Congratulations on the purchase of your LTI MapStar TruAngle angle encoder. The TruAngle calculates a turned horizontal angle that can be referenced to any desired point or direction. It works in conjunction with all our laser rangefinders that have an inclinometer for complete 3D position measurements with X, Y and Z coordinates. The modular design allows you to pivot the laser a full 90° up or down while maintaining the rotary encoder level, providing the greatest possible accuracy and range of motion.

One of the major advantages of the TruAngle is that it is not affected by local magnetic interference. There are so many applications, like urban environments for example, where you may need to position objects, but can not use an electronic compass because your surroundings could compromise your accuracy.

Features of the TruAngle:

- Simple 2-button interface
- Friction Lock Mechanism
- Bubble Level
- LCD
- Backlight
- Serial Interface with Auto Download from laser to data collector




Figure #1

Basic Package

- MapStar TruAngle
- Laser Cable
- Download Cable
- Side Brackets (1 set):
 - Short (Impulse / TruPulse 200 / TruPulse 360)
 - Short and Laser Mounting Bracket (TruSpeed Sx / TruPulse 200X / TruPulse 360R)
 - Tall (UltraLyte)
- 2 AA batteries
- User's Manual
- Padded shipping box

Accessories

- Laser mounting brackets
- Tripod / Staff
- Tribrach & Tribrach adapter
- Mounting hardware
- Serial data cable (remote trigger option)
- Carrying case
- Software solutions
- Data Collectors

① To learn more about any of the items listed above, please contact LTI,
LTI Sales Representative or Authorized Dealer.

Section #2 - Quick Start

1. Install the batteries ([Page 4](#)).
2. Mount side brackets, laser, tripod and then attach cables ([Pages 5 - 6](#)).
3. Use the bubble level to level the unit ([Page 6](#)).
4. Long press the ON button to power on the unit ([Page 7](#)).
5. Index the encoder ([Page 9](#)).
6. Zero the unit when "0.00" is flashing by pressing the OK button or firing the laser. When the TruAngle is rotated, the display not flash and will update with angle measurements.
7. Fire the laser to take an angle measurement. Laser and angle measurement data is automatically downloaded through the DATA serial port.
8. When finished, long press both buttons to power off the TruAngle.



Figure #2

Section #3 - Using the TruAngle

Loading the Batteries

Two AA batteries are required to power the TruAngle.
The Battery Door is located on the left side of the TruAngle.

- ① Use a flat head screwdriver or coin to remove or secure the battery door.
- 1. Remove the Battery Door by turning the screw counter-clockwise.
Note that Battery Doors tabbed edge serves as the hinge.
- 2. Insert the two batteries as shown in the figure.
- 3. Replace the Battery Door by inserting the tabbed edge of the door into the slot.
- 4. Secure the Battery Door by turning the screw clockwise.




Figure #3

Battery Indicator

The TruAngle continuously monitors its power source. LTI has defined the acceptable battery voltage range to guarantee correct operation.

The battery voltage icon is located in the lower right corner of the LCD.

When the battery voltage becomes too low, the unit will automatically power off. No indications.

Appearance of the Battery Icon	Explanation
	2 segments and battery outline lighted. Approximately 8 hours of use remain.
	1 segment and battery outline lighted. Approximately 5 hours of use remain.
	Battery outline lighted. Approximately 2 hours of use remain.

Attaching the Side Brackets and the Laser

- i** • The required laser mounting bracket depends upon which laser you are using (Impulse, TruPulse 200, TruPulse 200X, TruPulse 360, TruPulse 360R, TruSpeed Sx or UltraLyte). Please contact LTI if you need assistance.
- When attaching the laser to the side brackets, do not over-extend the side brackets.





Figure #4

1. Attach the laser mounting bracket to the laser.
2. Attach right and left side brackets to the TruAngle.
 - The short side brackets are designed for use with the Impulse and the TruPulse.
 - The tall side brackets are designed for use with the UltraLyte
3. Attach the laser mounting bracket to the side bracket. The side bracket should be secure, but should not be over tightened.

Connecting the Cables

- Connect either end of the supplied laser data cable to the laser's serial port and the other end to the TruAngle's serial port labeled "LASER".
- Connect one end of the download cable to the data collector and the other end to the TruAngle's serial port labeled "DATA".



(Right Side View of the TruAngle)

Figure #5

Cable Crimp

As Figure #6 shows, the side bracket design includes a cable crimp. You can use the cable crimp to hold the cables and keep them from interfering with your work.





Figure #6

Leveling the TruAngle

The bubble level is used to level the TruAngle.

1. Look at the position of the bubble within the bubble level. When the bubble is centered inside the circle, the TruAngle is level.
2. To align the bubble within the circle, adjust the tribach or tripod the TruAngle is mounted on.

Looking at Figure #7, the yellow dot represents the bubble. [A] shows that the TruAngle is not level. [B] shows that the TruAngle is level.



[A]

[B]

Figure #7

Fine Adjust and Friction Lock

- The Fine Adjust wheel lets you precisely control the encoder's rotation. Movement of the wheel results in small angle update measurements. The Fine Adjust ratio is 66:1.
- Tightening the Friction Lock keeps the encoder from rotating by adding friction to the base plate and to the brake shoe which is attached to the chassis. Adjust as needed.

Button Names and Functions



Figure #7

Button		Function
	ON	Long press powers on the TruAngle.
	BL	Shows the Display Test at power on until the button is released (Page 8).
	OK	When the TruAngle is already powered on, long press to turn on / off the backlight.
	ZERO	Short press to accept orientation and reference the TruAngle at the value displayed.
	BS	Long press to activate the Zero Mode.
		Short press to activate the Backsight Mode.
		Press and hold both buttons until the TruAngle powers off.

- ⓘ This manual simplifies the button names to relate to current function instead of matching the TruAngle's label. For example, instead of "Press the ON BL OK button to activate the backlight", this manual would state "Press the BL button to activate the backlight".

Power ON the TruAngle

To power on the TruAngle, long press the ON button. Briefly, the LCD should look like Figure #8 and the backlight will also be on. Next the LCD should look like Figure #9, prompting you to index the encoder ([Page 9](#)).



Figure #8



Figure #9

Extend the Display Segment Test

Extending the Display Segment Test allows you to verify that all display indicators are working properly.

1. Press and hold the ON button. The LCD should look like Figure #8 (Page 7) and the Backlight should also be on.
2. Verify all display segments are lit.
3. Release the ON button. Upon releasing the ON button, the LCD should look like Figure #9 (Page 7).

Power OFF the TruAngle

To power off the TruAngle, long press both buttons simultaneously.

- i**
- To help save its batteries, the TruAngle has a factory-defined power off interval. The instrument will automatically power off if there is no activity for a period of 60 minutes. Instrument activity includes button presses and measurements.
 - The power off interval may be changed using the Time Out Interval serial command ([Page 13](#)).

Display the Firmware Version Number

The firmware version number provides manufacturing information about your TruAngle. It can only be viewed at power on.

1. Starting with the TruAngle powered off, long press both buttons. As an example, Figure #10 shows the firmware version number 1.14.
Note: Your TruAngle may display a different firmware version number.
2. Upon release of the buttons, the LCD should look like Figure #9, prompting you to index the encoder ([Page 9](#)).



Figure #10

For future reference, make note here of the firmware version number: _____.

Turn the LCD Backlight On or Off

When working in low-light conditions, you may find it easier to read the display screen if the LCD backlight is toggled on. Long press the BL button at anytime to toggle the LCD backlight on or off.

- i**
- To conserve battery power, you should only use the backlight when necessary.

Indexing the Encoder

Each time the TruAngle is powered on, the LCD will display "ind" (see [Figure #9 on Page 7](#)) prompting you to index the encoder.

1. Rotate the TruAngle clockwise or counter clockwise one complete rotation (360°).
2. Once the index has been found, the 0.00° LCD characters will flash.

i As you are rotating the TruAngle, the index may be found before the unit has been rotated the complete 360°. This is not a problem and will not change the calibration.

Zeroing the Unit

Once the encoder is indexed, the 0.00° LCD characters will flash to prompt you to zero the unit.

1. Short press the OK button or fire the laser. Firing the laser downloads a serial data string to zero the unit.
2. The 0.00° LCD characters will be displayed steady instead of flashing. Angle measurements and the display will update as the unit is rotated.

Entering A Non-Zero Backsight

Shooting a BackSight is the process of pairing a reference angle, or BackSight angle, with a selected direction, and must be done upon every change of station. The default is to Zero your backsight angle while this routine allows you to enter a non-zero backsight value.

1. Power on the TruAngle, index the encoder, and then short press the OK button to enter the Measurement Mode.
 2. Short press the BS button to activate the Backsight Mode and start updating the display. The display flashes during this process.
 3. Rotate the TruAngle until the desired Backsight value is displayed. Use the Fine Adjust wheel to assist in displaying the correct value. Note that some hundredths values will not display - simply stop at the nearest value.
 4. Short press the BS button to freeze or lock the number in the display. The number will remain solid and will not update if the TruAngle is turned.
 5. Rotate the TruAngle until the instrument is pointing in the desired direction.
- i** At this point, if you want to change the backsight value, just short press the BS button. The display will be flashing, prompting you to enter the new backsight value.
6. Press the OK button or fire the laser on the target to accept the measurement. The display & backlight will flash 3 times, indicating the new backsight value has been set. The display will be steady instead of flashing. The unit is ready for the next angle measurement.

Removing the Non-Zero Backsight Value

There are two ways to remove the Backsight value:

- Long press of the ZERO/BS button. This will clear the Backsight value and return the unit to the zeroing mode. The "0.00" would begin to flash, indicating the unit is ready to be zeroed.
- Power the unit off and then power the unit on to set the zero.

Taking a Measurement

To measure an angle after zeroing the unit or setting a non-zero backsight:

1. Rotate the TruAngle until the instrument is pointing in the desired direction.
2. Fire the laser.
 - When laser is fired and a measurement is recorded, the TruAngle will also record the current angle measurement and display that angle measurement on the LCD. The measurement display and backlight will flash three times. Then the angle measurement will display steady.
 - The flash indicates the measurements are being downloaded through the data serial port automatically.
 - The TruAngle is ready for a new angle measurement.
3. Repeat steps 1 and 2 for each new measurement.

Error Codes

The error code listed below and shown in Figure #11 may be displayed on the LCD:

- Err 2: Memory Checksum Failure. If you see this code, try cycling the power OFF and ON, and then repeat the measurement. If the error persists, please contact Laser Technology, Inc. for assistance.
- i** Additional error codes (messages) may be output through the serial port. See [Page 15](#) for more information.



Figure #11

Section #4 - Managing Serial Data

The TruAngle's two serial ports are used to communicate with external devices. The one labeled LASER to an LTI laser product and the one labeled DATA to a data collector or PC. In normal operation, the laser's Fire button is pressed and data is automatically downloaded to the TruAngle. It then fires, inserts the angle value into the data string and automatically sends it out the DATA port. In addition, commands can be sent from the data collector/PC to the TruAngle or laser; such as parameter change commands ([Page 13](#)) and a remote trigger command to Fire the laser (see below). Figure #12 shows the data flow.

The cables, data collectors, and software needed for remote operations are available from LTI or an Authorized Dealer.




Figure #12

NMEA Compliance

The TruAngle uses the LTI CR400 data format follows the guidelines of the NMEA 0183 Standard for Interfacing Marine Electronic Navigational Devices, Revision 2.0:

- NMEA 0183 provides for both standard and proprietary data formats. Since none of the standard formats are useful for the data transferred from the Impulse, special proprietary formats are used. Rules described in the NMEA standard governing general message structure, leading and trailing characters, numeric values, delimiting character, checksums, maximum line length, data rate, and bit format are followed exactly.
- As required by NMEA 0183, the CR400-format does not respond to unrecognized header formats, malformed messages, or messages with invalid checksums.

Laser Settings

- **Impulse 200 and 200 LR:** Select the CR400 message format and the Auto Download option. The Impulse will not communicate with the TruAngle if the IP200 download format is active.
- **TruPulse Series:** The CR400 message format with Auto Download is only option offered in the unit. No settings are necessary.
- **TruSpeed Sx:** Select the CR400 message format. The TruSpeed Sx will not communicate with the TruAngle if the TruSpeed download format is active.
- **UltraLyte 200 and 200 LR:** Select the CR400 message format. The UltraLyte will not communicate with the TruAngle if the UL200 download format is active.

Remote Triggering

It is possible to remotely trigger the TruAngle by using an external computer, data collector, or switch closure. Remote triggering uses an open collector closure to ground or an active low TTL or RS232 level signal to the 'trigger' pin on the serial connector. It requires a special order download cable that connects the remote trigger signal from the encoder to the 'RTS' output signal of a computer's serial port.

When using a serial cable with a remote trigger connection hard-wired, care must be taken to control the state of the RTS signal from the host computer. Often times the default state of the RTS signal will be low, causing an inadvertent trigger. Since the remote trigger signal is treated the same as a button press on the TruAngle, holding the signal low is identical to holding down a button, which prevents a response to any additional buttons that are pressed.

Format Parameters

The TruAngle serial interface uses RS-232 $\pm 12V$ signal levels and data format. The format parameters are set to:

- Baud Rate 4800 BPS
- Start bit 1
- Data bits 8
- Stop bit 1
- Parity None

Serial Ports Pin-out Assignments




Figure #13

Serial Commands

- Serial commands that start the "\$" character pass through the TruAngle to the laser. For information about these serial commands, please refer to the user's manual that shipped with your laser.
- Serial commands that start with the "#" character are intercepted and acted upon by TruAngle.
- *TruPulse Series and TruSpeed Sx Lasers Only:* Serial commands can be sent to the laser via a PC, while cabled to the TruAngle. For example, the \$GO command will fire the laser, capture a measurement, and then download the serial data string from the laser to TruAngle, capture the angle measurement and then download the complete serial data string to the PC. For more laser serial commands please refer to the user's manual that shipped with your laser.

Serial Requests

Instrument Identification

Command: **\$ID<CR><LF>**

where:
= message identifier
ID = refers to TruAngle Firmware Version
<CR> = carriage return
<LF> = line feed

Instrument Reply: #ID,LCAE,*version number,date*<CR><LF>
Example Reply: #ID,LCAE,1.14,07-28-10<CR><LF>

Serial Commands

Zero the Display

Command: **#ZERO<CR><LF>**

where: **#** = message identifier
ZERO = refers to Zero the Display
<CR> = carriage return
<LF> = line feed

Instrument Reply: **#OK<CR><LF>**

Report Current Angle (shown on the LCD)

Command: **#ANG<CR><LF>**

where: **#** = message identifier
ANG = refers to Report the Current Angle
<CR> = carriage return
<LF> = line feed

Example Reply: **#ANG,23.96<CR><LF>**

Power Down the TruAngle

Command: **#PWR<CR><LF>**

where: **#** = message identifier
PWR = refers to Power Down the TruAngle
<CR> = carriage return
<LF> = line feed

Example Reply: **#OK<CR><LF>**

Time Out Interval

The factory default Time Out Interval is 60 minutes ([Page 8](#)). This command allows you to change the Time Out interval.

Get: **#TO<CR><LF>**
Reply: **#TO,n<CR><LF>**

Set: **#TO,n<CR><LF>**
Instrument Reply: **#OK<CR><LF>**

where: **#** = message identifier
TO = refers to the Time Out Interval
n = 5 5-minute time-out
 10 10-minute time-out
 60 60 for 60-minute time-out
 XXXXX XXXXX-minute time-out
 65535 (any number between 0 and 65534)
 No Time Out Interval. Always on.
<CR> = carriage return
<LF> = line feed

Example: **#TO,10<CR><LF>** *Sets the Time Out Interval to 10 minutes.*

Backlight Status

Get:	#BL<CR><LF>						
Instrument Reply:	#BL,n<CR><LF>						
Set:	#BL,n<CR><LF>						
Instrument Reply:	#OK<CR><LF>						
where:	<table border="0"> <tr> <td>#</td><td>= message identifier</td></tr> <tr> <td>BL</td><td>= Backlight Status</td></tr> <tr> <td><i>n</i></td><td> = 0 = Backlight OFF 1 = Backlight ON </td></tr> </table>	#	= message identifier	BL	= Backlight Status	<i>n</i>	= 0 = Backlight OFF 1 = Backlight ON
#	= message identifier						
BL	= Backlight Status						
<i>n</i>	= 0 = Backlight OFF 1 = Backlight ON						

Example: #BL,1<CR><LF> *Turns the backlight ON.*

Backsight

Set: #BS,*n*<CR><LF>
Instrument Reply: #OK<CR><LF>

where:

#	= message identifier
BS	= Backsight
<i>n</i>	= 1 = Puts instrument in Backsight mode (display flashes so display angle can be set). 2 = Locks Backsight angle in display so instrument can be aimed at target. 3 = Locked angle is set as current angle, display flashes 3 times, and normal operation resumes. 4 = Cancels Backsight operation after a #BS,1 or #BS,2 command and returns the instrument to normal operation.

<CR> = carriage return
<LF> = line feed

Example: #BS,1<CR><LF> Turns on the backlight.

TruPulse Series and TruSpeed Sx Only

Serial commands can be sent to the TruPulse series and TruSpeed Sx via PC, while cabled to the TruAngle. For example, the \$GO command will fire the laser and capture a measurement. Then the laser will download the serial string into the TruAngle, capture the angle measurement and download the data string to the PC. For information about additional commands, please refer to the user's manual that shipped with your laser.

Error Messages

If an error is encountered, an error message will be output instead of the #OK message.

#ER,n<CR><LF>

where:

#	= message identifier
ER	= Error
<i>n</i>	= 1 = Command syntax error (unrecognized character etc.) *Try to enter command again. 2 = Memory checksum failure *If you see this code, try cycling the power OFF and ON, and then repeat the measurement. If the error persists, please contact Laser Technology, Inc. for assistance. 3 = Instrument is in Index Mode *Rotate the unit to set the index (Page 9). 4 = Instrument is in Backsight Mode *Set the non-zero backsight or cancel Backsight Mode.
<CR>	= carriage return
<LF>	= line feed

Example: #ER,3<CR><LF> Instrument is in Index Mode.

Section #5 - Caring for the TruAngle

Operating Temperature

The TruAngle components are rated for a temperature range of -22° to 122° F (-30° to 50° C). Do not expose the instrument to temperatures outside this range.

Moisture and Dust Protection

The Angle Encoder is sealed to provide protection from normally expected field conditions. It is protected from dust and water, and features temporary submersion resistance.

If water leakage is suspected:

1. Power OFF the Angle Encoder.
2. Remove the batteries.
3. Air-dry the encoder at room temperature with the battery compartment open.

Shock Protection

The TruAngle is a precision instrument and should be handled with care. It will withstand a reasonable drop shock. If the encoder is subjected to a severe mechanical shock, you should power on the instrument and index the encoder ([Page 9](#)).

Cleaning and Storage

Clean the TruAngle after each use. Before returning it to its case, check for the following items:

- **Excess moisture.** Towel off excess moisture, and air-dry the instrument at room temperature with the battery compartment open and the batteries removed.
- **Exterior dirt.** Wipe exterior surfaces clean. Use isopropanol to remove dirt and fingerprints from the exterior surfaces.
- **Batteries.** If you do not expect to use the TruAngle again soon, remove the batteries before storing it.

Display Screen

It is a good idea to periodically check the display screen to make certain that all display segments are working properly. For more information, see Extend the Display Segment Test ([Page 8](#)).

Section #6 - Troubleshooting & Tips

If you see this issue...	... take this action
The angles output by the TruAngle do not appear to be accurate.	Make sure the TruAngle is level before you power it On (Page 6).
	When mounting the TruAngle, make sure the base is completely tight to the top of the tripod, adapter or staff you are using; and does not rotate. To aid in this, tighten down the friction lock so the entire unit will not rotate.
When turning the unit, the gears seem to grind.	Loosen the friction lock until it moves smoothly.
After referencing the TruAngle, the data strings are not being output. The display is updating when rotated but now it is flashing.	The ZERO/BS button was inadvertently pressed. Cycle the Power Off/On, and re-reference the unit and try again.
The display reads "ind" and will not go into the Zero backsight mode.	Rotate the TruAngle through 360 degrees until the display starts to flash "0.00".

Section #7 - Specifications

Accuracy:	$\pm 0.1^\circ$ staff mounted $\pm 0.05^\circ$ tripod mounted		
Range:	0° to 359.99°		
Display Resolution:	0.01°		
Angle Resolution:	0.01°		
Measurement Units:	Degrees		
Power supply:	2 AA batteries 8 hours continuous use		
Environment:	Water and Dust Resistant: IP54		
Temperature:	Operating: -22° to $+122^\circ$ F (-30° to $+50^\circ$ C) Storage: -40° to $+176^\circ$ F (-40° to $+80^\circ$ C)		
Size:	Height to top of bubble level: 5.6 in 14.2 cm Diameter: 4.55 in 11.6 cm Width with tall side brackets: 5.65 in 14.4 cm Width with short side brackets: 5.41 in 13.7 cm Short Side Bracket total height: 10.43 in 26.5 cm Tall Side Bracket total height: 15.08 in 38.3 cm		
Weight:	2.25 lbs (1.02 kg) Weight includes batteries, does not include side brackets		
Construction:	Fiberglass filled polycarbonate		
Tripod Mount:	5/8 inch threaded insert		
Data Output:	RS232 Serial - NMEA 0183 format		
Sensor Type:	High resolution optical encoder		

Section #8 - LTI Limited Warranty

Standard Limited Product Warranty

Laser Technology, Inc. ("LTI") warrants products it manufactures to be in good working order, free from defects in materials and workmanship, for a period of 12 months from the date of purchase from LTI or an authorized LTI dealer.

In order to activate your one-year Limited Warranty, please register at www.lasertech.com/warranty. If you do not have Internet access, please complete the Limited Warranty Registration Card and return to Laser Technology, Inc. (LTI), within 30 days of purchase.

Warranty Exclusions

To the fullest extent allowed by law, LTI hereby disclaims all other express or implied warranties for the product, including, without limitation, any warranty as to merchantability or fitness for a particular purpose.

This limited warranty does not include service or repair of damage to the product resulting from accident, disaster, misuse, abuse, non-LTI modification of the product, batteries or damage caused by batteries used in our products. If your product uses LTI software which requires registration, that registration must also be completed to benefit from this limited warranty. Software reproduction is forbidden. LTI has no obligation to modify or upgrade a product once sold.

Limitation of Liability

In no event will LTI be liable for damages including any lost profits, lost savings or other incidental or consequential damages arising from the use or inability to use such product. Furthermore, LTI shall not be held responsible if an LTI authorized dealer has been advised of the possibility of such damage, or for any claim by another party. Any responsibility and/or liability of LTI shall be limited to the maximum amount to the original purchase price.

Remedy

To obtain service during the one-year warranty period, call LTI's Service Center or visit www.lasertech.com/rma for a Return Merchandise Authorization number. Send the product to LTI or an Authorized Service Center with proof of purchase date. If the product is delivered by mail, you agree to insure the product or assume the risk of loss or damage in transit, and to prepay shipping costs for door-to-door delivery. LTI will, at its option, repair or replace the product at no additional charge, except as set forth within this limited warranty. Replacement parts and products may be new or reconditioned. Replaced parts or products become the property of LTI.

Index

A

accessories 3
accuracy 18
angle resolution 18

B

backlight 8
backlight status 14
backsight 9, 14
basic package 3
batteries 16
 installing 4
battery door 2
battery indicator 4
BL button 7
BS button 7
bubble level 2
 positioning 6
buttons 7

C

cable connections 5, 6
cable crimp
 side bracket 6
cleaning 16
construction 18

D

data output 18
DATA port 6
dirt 16
display resolution 18
display test 8
drop shock 16
dust protection 16

E

environmental rating 2, 18
error code
 Err 2 10
error message
 serial output 15

E

features 2
fine adjust 2, 7
firmware version 8
friction lock 2, 7

G

gear noise 17

I

Impulse 5, 11
ind 7, 17
indexing the encoder 9
instrument id 12

L

LASER port 6
laser settings 11
LCD 2, 16

M

maintenance 16
measurement 10
measurement units 18
moisture 16
moisture protection 16

N

NMEA compliance 11
non-zero backsight 9
 removing 9, 10

O

OFF button 7
OK button 7
ON button 7

P

power down 13
power supply 18
powering
 OFF 8
 ON 7
precautions 2

R

range 18
remote trigger 11
report current angle 13

S

sensor type 18
serial data
 format parameters 12
serial ports 6, 11
 pin-out assignments 12
side bracket
 cable crimp 6
side brackets 5
size 18
specifications 18

T

temperature range 2, 16, 18
test
 LCD 8
threaded insert 2
time out interval 8, 13
tripod mount 2, 18
troubleshooting 17
TruPulse 5, 11, 14
TruSpeed Sx 5, 11, 14

U

UltraLyte 5, 11

V

version number 8
views 2

W

weight 18

Z

ZERO button 7
zero the display 13
zeroing the encoder 9