# LTI TruPulse 360/R Interface to ProStar GeoCorp's Pointman app



Quick Reference Guide





### Overview

ProStar GeoCorp has written a Range/Azimuth interface for the TruPulse 360/R into their Pointman app for Android. Through the standard Locator function, laser measurements can automatically be recorded and offset positions calculated.

#### **Compatible products**

- TruPulse 360/R
- Pointman ver 2.0.4.384

### **Basic Steps**

- Start Pointman and Connect Laser
- Configure Locator and GPS
- Record Offset Locations
  - Point
  - Line





# Start Pointman and Connect Laser

The TruPulse 360/R's Bluetooth module is compatible with Windows and Android. The first time you connect the laser to your device, it will need to be paired.

- 1. In the laser Settings menu, turn On the Bluetooth **"bt\_on".** On the device, start Pointman and from the Menu, select **Settings** (Figure 1)
- 2. Under Devices, tap the Configure Bluetooth button (Figure 2)
- 3. Select your TP360 from the list, enter the passcode "1111" and tap OK (Figure 3)
- 4. Confirm the laser is paired to the device and press the device's **Back** key to exit (Figure 4)



Figure 1

Figure 3



BLATER TECHNOLOGY E



# Configure Locator & GPS

The Pointman app has integrated the LTI TruPulse 360/R product as another choice for a Locator device.

- 5. Under Devices, pull down the list of **Locators** and select the laser (Figure 5)
- Under the pull-down list for **Type**, choose Laser Tech (Figure 6) 6.
- 7. Make sure your **GPS** type is correct and an **Antenna** height is entered (Figure 7) \*Note: the app assumes the laser is held at this same height when measuring
- Confirm all settings are correct and tap **Done** (Figure 8) 8.

	🍳 🗟 📓 2:27 PM		9 🛡 🖹 🖬 2:27 PM		🕈 🖝 🖹 🖬 2:27 PM			9 🐨 🖹 🔳 2:27 PM
Setting	js Close	Settings	Close	Settings	Close	Settings	s	Close
Open		Open		Open		Open		
	<ul> <li>Set map to current location on open</li> <li>Set map to last visited location on open</li> <li>Always accept legal agreement</li> <li>Automatically login</li> </ul>	<ul> <li>Set map to current location on of</li> <li>Set map to last visited location</li> <li>Always accept legal agreement</li> <li>Automatically login</li> </ul>	on open	<ul> <li>Set map to current location</li> <li>Set map to last visited location</li> <li>Always accept legal agreen</li> <li>Automatically login</li> </ul>	ation on open		<ul> <li>Set map to current location on a</li> <li>Set map to last visited location</li> <li>Always accept legal agreement</li> <li>Automatically login</li> </ul>	on open
Devices		Devices		Devices		Devices		
GPS:	Internal •	GPS: Internal v		GPS: Internal Antenna: 4.5	•	GPS:	Internal 🔻	
Antenna: Locator:	4.5 feet       None     V         No Type	Antenna: 4.5 Locator: TP360RB-000348	feet No Type	Locator: TP360RB-000348	feet ▼ Laser Tech ▼	Antenna: Locator:	4.5 TP360RB-000348	feet Laser Tech 🔹
Tag Reader:	None TSL • TP360RB-000348 Commgate observours	Tag Reader: None  Configure Bluetooth	No Type Vivax Fuji	Tag Reader: None Configure Bluetooth	▼ TSL ▼	Tag Reader:	None   Configure Bluetooth	TSL
Мар		Мар	Radiodetection	Мар		Мар		
<ul> <li>Start GPS on placemark creation</li> <li>Show As-Built settings on move</li> <li>Show Stake option on placemark selection</li> </ul>		<ul> <li>Start GPS on placemark creation Dynatel</li> <li>Show As-Built settings on move Subsite</li> <li>Show Stake option on placemar</li> </ul>		<ul> <li>Start GPS on placemark creation</li> <li>Show As-Built settings on move</li> <li>Show Stake option on placemark selection</li> </ul>		<ul> <li>Start GPS on placemark creation</li> <li>Show As-Built settings on move</li> <li>Show Stake option on placemark selection</li> </ul>		
Data Dictionary		Data Dictionary		Data Dictionary		Data Dictionary		
Figure 5		Figure 6		Figure 7		Figure 8		



Figure 8

#### **ELATER TECHNOLOGY**

# **Record Offset Locations - Point**

Point, Line and Area features may be easily mapped from one location.

- 9. Open a Project and select **New** at the upper right (Figure 9)
- 10. Select a Point feature type such as **Point of Concern** (Figure 10)
- 11. Put the laser in either HD or SD mode and **shoot** to the target (Figure 11)
- 12. Pointman will emit an audio **chirp** when the laser data is received and the **offset location** will display on the map (Figure 12)











Figure 9

Figure 10

Figure 11

Figure 12

BLATER TECHNOLOGY 🗄

# **Record Offset Locations - Line**

Point, Line and Area features may be easily mapped from one location.

- 13. Select a Line feature from the list, such as **Electrical** (Figure 13)
- 14. Measure to one end of the feature (Figure 14)
- 15. The offset point will display along with the distance measured to it (Figure 15)
- 16. Shoot the next point in the Line feature, the app will chirp and the **new point** will display (Figure 16). The distance to it, as well as from the last point, will be shown. Continue measuring to more points on the line in this same manner and tap **Finish** when done.







Figure 13

Figure 14

Figure 15

Figure 16

BLATER TECHNOLOGY



### **Product Resources**

#### Product Page/User's Guides: https://www.lasertech.com/TruPulse-Laser-

#### Rangefinder.aspx



#### http://www.prostarcorp.com/pointman\_locate.htm



#### Stay informed! Find out about Laser Technology products, updates, and training resources by keeping track of us on FaceBook (/LaserTechnologyInc), Twitter (@LaserTechPro) and YouTube (/user/LaserTechPro)

### BLATER TECHNOLOGY

# Contact Laser Technology, Inc.

### **Questions regarding the interface of our TruPulse** 360 into Pointman?

### Please contact us at:

1.800.280.6113 or 1.303.649.1000

### info@lasertech.com

Laser Technology, Inc. 6912 S. Quentin St. Centennial, CO 80112

www.lasertech.com

